

Installation Guide

Use with any Cadet model HW, CE(F), CS(F), or CM heater

Information is also available on our website:

<http://cadetheat.com/products/wall-heaters>


PROVIDED:

- (1) Grounding Screw
- (1) Mounting Screw

TOOLS REQUIRED:

- Phillips Screwdriver
- Straight Screwdriver
- Wire Strippers
- Drill and Drill bits
- (4) Wall Fasteners
- Insulated Wire Connectors
- Conduit Connector
- Strain Relief Connector


HORIZONTAL MOUNT: MODEL HW



ATTACH HEATER ASSEMBLY HERE

THIS HOLE IS UNUSED FOR MODEL HW


VERTICAL MOUNT: MODELS CE(F), CS(F), and CM



ATTACH HEATER ASSEMBLY HERE

ATTACH GRILL HERE

HORIZONTAL MOUNT: MODELS CS(F), and CM



ATTACH HEATER ASSEMBLY HERE

ATTACH GRILL HERE

Important Instructions

⚠ WARNING

When using electrical appliances, basic precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons. If you are uncomfortable working with electrical appliances, unable to follow these guidelines, or do not have the necessary equipment; consult a licensed electrician. All steps must be followed.

Installation Instructions

NOTE: Before mounting the surface wall can, please read your original product Owner's Guide or go to cadetheat.com for your heater's minimum placement clearances.

STEP 1 Mount the Surface Wall Can

Review the surface wall can label for correct direction (as noted by the UP arrows) before mounting. In the vertical mounting position the element of the heater assembly will be at the top. In the horizontal mounting position the element of the heater assembly will be to the left.

Mount the surface wall can securely to the wall, using appropriate wall fasteners (not included). Refer to your original product Owner's Guide for minimum heater clearances from floor, adjacent walls and ceiling.

STEP 3 Install Heater Assembly and Grill

Install heater assembly and grill or decorative cover kit according to the installation instructions included in your original product Owner's Guide.

STEP 2 Route Supply Wires

Feed supply wires through a conduit connector (not included), leaving 14 inches of wire. Remove a knockout in the surface wall can closest to the supply wires. Install a strain relief connector (not included) in the surface wall can knockout. Feed supply wires through the strain relief connector in the surface wall can and secure them. Connect supply ground wire to grounding screw.

NOTE: All wiring outside of the surface wall can must be protected by conduit or other approved devices.

Warranty

For more effective and safer operation and to prolong the life of the heater, read the Owner's Guide and follow the maintenance instructions. Failure to properly maintain the heater will void any warranty and may cause the heater to function improperly. Warranties are non transferable and apply to original consumer only. Warranty terms are set out below.

LIMITED ONE-YEAR WARRANTY: Cadet will repair or replace any CADET product, including thermostats, found to be defective within one year after the date of purchase.

These warranties do not apply:

1. Damage occurs to the product through improper installation or incorrect supply voltage;
2. Damage occurs to the product through improper maintenance, misuse, abuse, accident, or alteration;
3. The product is serviced by anyone other than Cadet;
4. If the date of manufacture of the product cannot be determined;
5. If the product is damaged during shipping through no fault of Cadet;
6. The use of unauthorized accessories or unauthorized components constitutes an alteration and voids all warranties. Refer to Cadet website or call customer service at 855.CADET.US for list of authorized accessories and components.
7. CADET'S WARRANTY IS LIMITED TO REPAIR OR REPLACEMENT AS SET OUT HEREIN. CADET SHALL NOT BE LIABLE FOR DAMAGES SUCH AS PROPERTY DAMAGE OR FOR CONSEQUENTIAL DAMAGES AND/OR INCIDENTAL EXPENSES RESULTING FROM BREACH OF THESE WRITTEN WARRANTIES OR ANY EXPRESS OR IMPLIED WARRANTY.

8. IN THE EVENT CADET ELECTS TO REPLACE ANY PART OF YOUR CADET PRODUCT, THE REPLACEMENT PARTS ARE SUBJECT TO THE SAME WARRANTIES AS THE PRODUCT. THE INSTALLATION OF REPLACEMENT PARTS DOES NOT MODIFY OR EXTEND THE UNDERLYING WARRANTIES. REPLACEMENT OR REPAIR OF ANY CADET PRODUCT OR PART DOES NOT CREATE ANY NEW WARRANTIES.

9. These warranties give you specific legal rights, and you may also have other rights which vary from state to state. Cadet neither assumes, nor authorizes anyone to assume for it, any other obligation or liability in connection with its products other than as set out herein.

If you believe your Cadet product is defective, please contact Cadet Manufacturing Co. at 855.CADET.US, during the warranty period, for instructions on how to have the repair or replacement processed. Warranty claims made after the warranty period has expired will be denied. Products returned without authorization will be refused.

Parts and Service

Visit cadetheat.com/parts-service for information on where to obtain parts and service.



Reduce-Reuse-Recycle

This product is made primarily of recyclable materials. You can reduce your carbon footprint by recycling this product at the end of its useful life. Contact your local recycling support center for further recycling instructions.

SAVE THESE INSTRUCTIONS